

FIG. 1A




FIG. 1B




FIG. 1C




FIG. 2





FIG. 3






FIG. 5

Guidance contents of each display region

Item	101		102	
	Display state	Display content	Display state	Display content
Upward arrow	Display		—	
Rightward arrow	—		—	
Downward arrow	Display		—	
Leftward arrow	—		—	
Soft key	—	—	Display	Playback
State display	—	—	Display	Stop
Operation guide	—	—	—	—

FIG. 6




FIG. 7

	Previous synthesis result (101)		Obtained result(102)		Synthesis result	
	Display state	Display content	Display state	Display content	Display state	Display content
Upward arrow	—		Display		Display	
Rightward arrow	—		—		—	
Downward arrow	—		Display		Display	
Leftward arrow	—		—		—	
Soft key	Display	Playback	—	—	Display	Playback
State display	Display	Stop	—	—	Display	Stop
Operation guide	—	—	—	—	—	—

FIG. 8




FIG. 9




FIG. 10

Item	Use state	Display position (vertical/horizontal)	Display size (width/height)
Upward arrow	Display	(50,0)	(10,10)
Rightward arrow	Display	(60,10)	(10,10)
Downward arrow	Display	(50,20)	(10,10)
Leftward arrow	Display	(40,10)	(10,10)
Soft key	Display	(100,0)	(40,30)
State display	Display	(150,0)	(40,30)
Operation guide	No-display	(0,0)	(40,30)

FIG. 11

Guidance contents of each display region

Item	801		802		804		805	
	Display state	Display content	Display state	Display content	Display state	Display content	Display state	Display content
Upward arrow	Display		—		Display		—	
Rightward arrow	—		—		—		Display	
Downward arrow	Display		—		Display		—	
Leftward arrow	—		—		—		Display	
Soft key	—	—	Display	Playback	—	—	—	—
State display	—	—	Display	Stop	—	—	—	—
Operation guide	—	—	—	—	—	—	—	—

FIG. 12

In the case where 802 is operated

Item	Previous synthesis result (802)		Obtained result(805)		Synthesis result	
	Display state	Display content	Display state	Display content	Display state	Display content
Upward arrow	—		—		—	
Rightward arrow	—		Display		Display	
Downward arrow	—		—		—	
Leftward arrow	—		Display		Display	
Soft key	Display	Playback	—	—	Display	Playback
State display	Display	Stop	—	—	Display	Stop
Operation guide	—	—	—	—	—	—

FIG. 13

In the case where 804 is operated

Item	Previous synthesis result (804)		Obtained result(805)		Synthesis result	
	Display state	Display content	Display state	Display content	Display state	Display content
Upward arrow	Display		—		Display	
Rightward arrow	—		Display		Display	
Downward arrow	Display		—		Display	
Leftward arrow	—		Display		Display	
Soft key	—	—	—	—	—	—
State display	—	—	—	—	—	—
Operation guide	—	—	—	—	—	—